BASIC MAST

A main tube Ø52 mm is held by 2 single/double collars connected to the vehicle or wall. A tube Ø45 mm slides inside up and down the Ø52.

Brackets

- Double bracket: an upper and a lower one.

- It is also possible to have a simple pump/wall bracket instead of the double collar, which would keep the mast closer to the vehicle.

Basic Mast

View of the head with the mast in the closed position

Upper and Lower fixing brackets

with internal cables "B" 4x1,5 mm² or "C" 7x1 mm².

Basic Closed

Basic Open

Basic Mast

Closed Position